

Home Product Import GmbH Graf - Zeppelin - Str. 5 D - 46149 Oberhausen Germany	Tel. : +49-(0)208-9949330 Fax.: +49-(0)208-99493930 e-mail: info@h-p-i.de
---	---

LEDs Removal Instructions for LED Luminaire LED 燈具的 LEDs 拆卸說明 / LED 燈具的 LEDs 拆卸說明
--

HPI Article Nr. (HPI 产品编号):	180.004789	Date (日期):	Freitag, 11. März 2022
HPI Model Name (HPI 型号名称):	PLAIN	Revision Date	
Vendor Name (供应商名称):		(修订日期):	
Vendor Item Nr. (供应商产品编号):	LS7D03-1801F-2W	Version Nr. (版本号):	1


Procedure how to remove the LEDs from the luminaire (in text form):

如何從燈具中移除 LED 的程序 (以文本形式) / 如何从灯具中移除 LED 的程序 (以文本形式) :

Step 1 步驟/步骤 1	Open the lamp holder along the open indicator
Step 2 步驟/步骤 2	Release the L/N lead wire
Step 3 步驟/步骤 3	Remove front frame
Step 4 步驟/步骤 4	Loosen cable clamp
Step 5 步驟/步骤 5	Remove control gear
Step 6 步驟/步骤 6	remove light source

Drawings of how to remove the LEDs from the luminaire (without damaging the luminaire itself) corresponding to the above steps.

與上述步驟對應的如何從燈具中移除 LED（不損壞燈具本身）的圖示
 与上述步骤对应的如何从灯具中移除 LED（不损坏灯具本身）的图示



Prepared By (准备个人姓名) :	Coco
Jon Title (职称) :	Sales
Company Name (公司名称) :	

Signature with Company Chop
 (负责人签字加公司印章) :