

Home Product Import GmbH
Graf - Zeppelin - Str. 5
D - 46149 Oberhausen
Germany

LEDs Removal Instructions for LED Lur LED 燈具的 LEDs 拆卸說明 / LED 燈具的 LED

HPI Article Nr. (HPI 产品编号):	180.004965	Date (日期):
HPI Model Name (HPI 型号名称):	Spiro	Revision Date (修订日期):
Vendor Name (供应商名称):		Version Nr. (版本号):
Vendor Item Nr. (供应商产品编号):	4312101118	


Procedure how to remove the LEDs from the luminaire (in text form):

如何從燈具中移除 LED 的程序 (以文本形式) / 如何从灯具中移除 LED 的程序 (以文

Step 1 步驟/步骤 1	松开2个螺丝 Loosen 2 screws
Step 2 步驟/步骤 2	取出安装支架 Remove mounting bracket
Step 3 步驟/步骤 3	剪断驱动器连接线, 取出驱动器 Cut the drive connection cable
Step 4 步驟/步骤 4	取出PVC胶条 Remove the PVC cover
Step 5 步驟/步骤 5	用螺丝刀将其放在框架的角落, 然后撬出LED灯带 Use a screwdriver of the frame and pry out the LED strips
Step 6 步驟/步骤 6	用烙铁取下LED灯板上的导线 Remove the wires on the LED board
Step 7 步驟/步骤 7	
Step 8 步驟/步骤 8	
Step 9 步驟/步骤 9	
Step 10 步驟/步骤 10	

Drawings of how to remove the LEDs from the luminaire (without damaging the luminaires above steps).

與上述步驟對應的如何從燈具中移除 LED（不損壞燈具本身）的圖示
与上述步骤对应的如何从灯具中移除 LED（不损坏灯具本身）的图示



Prepared By (准备个人姓名):	
Jon Title (职称):	Product Engineer
Company Name (公司名称):	

Signature
(负责人签字)

Tel. : +49-(0)208-9949330
Fax.: +49-(0)208-99493930
e-mail: info@h-p-i.de

ninaire Ds 拆卸说明

Dienstag, 26. Dezember 2023

1

本形式) :

and remove the drive

r to place it in the corner

with a soldering iron

aire itself) corresponding to the



■■■■

with Company Chop

(加公司印章):

