

<b>Home Product Import GmbH</b> <b>Graf - Zeppelin - Str. 5</b> <b>D - 46149 Oberhausen</b> <b>Germany</b>	<b>Tel.: +49-(0)208-9949330</b> <b>Fax.: +49-(0)208-9949330</b> <b>e-mail: info@h-p-i.de</b>
---	--

<b>LEDs Removal Instructions for LED Luminaire</b> <b>LED 燈具的 LEDs 拆卸說明 / LED 燈具的 LEDs 拆卸說明</b>
--

HPI Article Nr. (HPI 产品编号):	<b>STIRS</b>	Date (日期):	<b>2021.9.8</b>
HPI Model Name (HPI 型号名称):	<b>180,004586</b>	Revision Date (修订日期):	
Vendor Name (供应商名称):		Version Nr. (版本号):	<b>1</b>
Vendor Item Nr. (供应商产品编号):	<b>CL-LED-Geometry-S001 RM 60W</b>		


Procedure how to remove the LEDs from the luminaire (in text form):

如何從燈具中移除 LED 的程序（以文本形式） / 如何从灯具中移除 LED 的程序（以文本形式）：

Step 1 步驟/步骤 1	Use a screwdriver to loosen the screws and remove the hanging plate
Step 2 步驟/步骤 2	Use pliers to cut off the nipple and separate the LED wire from the drive wire
Step 3 步驟/步骤 3	Use a screwdriver to loosen the screws to remove the chassis, and remove the first layer of LED strips
Step 4 步驟/步骤 4	Use a screwdriver to loosen the screws to remove the iron sheet, and remove the second layer of LED strips
Step 5 步驟/步骤 5	Use a screwdriver to loosen the screws to remove the iron sheet, and remove the third layer of LED strips
Step 6 步驟/步骤 6	Use a wrench to loosen the hex nut to remove the iron piece, and then use a screwdriver to loosen the screw Remove the iron sheet by the wire and remove the fourth layer of LED light strip
Step 7 步驟/步骤 7	
Step 8 步驟/步骤 8	
Step 9 步驟/步骤 9	
Step 10 步驟/步骤 10	

Drawings of how to remove the LEDs from the luminaire (without damaging the luminaire itself) corresponding to the above steps.

與上述步驟對應的如何從燈具中移除 LED（不損壞燈具本身）的圖示  
与上述步骤对应的如何从灯具中移除 LED（不损坏灯具本身）的图示



Prepared By (准备个人姓名):	Joanne Xu
Jon Title (职称):	Sales representative
Company Name (公司名称):	

Signature with Company Chop  
(负责人签字加公司印章):